



Sådan kommer du i gang med JJRC X11

1. Sæt dronen på en flad overflade
2. Tryk på "Lock" knappen på venstre side af fjernkontrollen. Når den bipper så slip knappen og forbered til pairing
3. Tænd dronen ved at trykke tænd knappen nede i 3 sekunder
4. Når fjernkontrollen bipper og lysene kommer frem på dronen, er pairing successfull
5. På dette tidspunkt samler vi dronen op og roterer den tre gange. vi
6. kan se, at for- og baglygterne på dronen bliver grønne og
7. blinker
8. Drej dronens hoved op og drej det tre gange. På dette tidspunkt, dronens frontlys blinker rødt, og baglygten blinker gult, angiver, at den geomagnetiske kalibrering er afsluttet.
Efter pairing er vellykket, kan mobiltelefonen oprette forbindelse til dronen normalt.

Quick start guide to JJRC X11

1. Put the battery into the remote control, first turn off the remote control power;
2. After turning on the power of the drone, first press and hold the red button of the remote control and then turn on the power of the remote control;
3. At this time, you can see that the drone information has been read on the remote control display;
4. After hearing the double beep of the drone, you can see that the front and rear lights of the drone become yellow and flashing;
5. At this time, we pick up the drone and rotate it three times. we can see that the front and rear lights of the drone become green and flashing;
6. Turn the drone's head up and rotate it three times. At this time, the drone's front light flashes red and the rear light flashes yellow, indicating that the geomagnetic calibration has been completed; 7. After the proofreading is successful, the mobile phone can connect to the drone normally.